













**IMPORTANT NOTICE:  
HARDWARE PACKAGE IS ATTACHED  
ON THE BOTTOM OF SEAT CUSHION.**

MODEL : B6508

(1)x1	(2)x1	(3)x1 (L)x1 (R)
		
Back Cushion	Seat Cushion	Left-Arm-L Right-Arm-R
(4)x1	(5)x1	(6)x1
		
TU026 Gas Lift W/ Cover	TU005 Nylon Base	Mechanism
(7)x5	<p>(A)x6   M6*28 ARM SCREW</p> <p>(B)x4  M8*22 MECHANISM SCREW</p> <p>(C)x4  M8*25 L-bar Screw</p>	
		
TU015 Caster		



**Insert and loosely tighten all screws. When assembly is completed, fully tighten all screws before using. This chair is only intended for sitting. Any other use will void the warranty.**

