















**IMPORTANT NOTICE:  
HARDWARE PACKAGE IS ATTACHED  
ON THE BOTTOM OF SEAT CUSHION.**

MODLE: B1676WT-GY

(1)x1	(2)x1	(3) (L)×1(R)×1
		
Back Cushion	Seat Cushion	Left-Arm Right-Arm
(4)x1	(5)x1	(6)x1
		
Mechanism	Gas Lift	Base
(7)x5	(8)x1	(9)x1
		
Casters	TU009-EXT	TU009
(A)x4 	M6*22 MECHANISM SCREW	
(B)x8 	M6*40 ARM SCREW	
(C)x2 	M6*35 BACK SCREW	
(D)x1 	ALLEN KEY	



**Insert and loosely tighten all screws. When assembly is completed, fully tighten all screws before using. This chair is only intended for sitting. Any other use will void the warranty.**

